

Important information!

- Please make sure you have read and understood this user guide as well as the user guide instructions before using your Handi-Move lifting equipment.
- If you are using the seat sling for the first time, please make sure that it is suitable for the person concerned.
- The seat sling is suitable for people with sufficient sitting balance. The person should be able to move between his or her (wheel)chair and chair independently or with an aid or passively (e.g. by means of lifting equipment).
- If, for whatever reason, there may be a possibility that the user slides out of the sling, you should use the safety belt(s)^(*). If use of the safety belt(s) does not guarantee complete security, do not use the seat sling.
- Before you start lifting, check that the user is positioned safely and the loops are well applied.
- Keep the user's arms in the seat sling.
- Never lift the user higher than necessary.
- Never leave a user hanging in the seat sling unattended.
- Please observe the washing instructions on the seat sling label for maintenance.
- Before each use, check the fabric, seams, stitching, loops and loop attachments for possible wear or damage. If you find any wear or damage, immediately stop using the seat sling and replace the item.
- Only use the seat sling in combination with Handi-Move lifting equipment.
- The maximum permissible weight for the seat sling to carry is 120 kg / 264.55 lbs.

Failure to observe the above instructions could lead to injuries to yourself or others.


- 1** Place the seat sling on the chair. The longest side should be positioned against the back of the chair, the shortest on the seat itself. The label is at the rear of the back section.



- 2** Move the person from (wheel) chair to chair.






- 3** Attach the loops to the spreader bar and lift.





- 4** The lifting position is determined by how much you tighten the yellow strap.

- Fully tightened = sitting position.
- Not tightened = recumbent position.



- 5** Seat sling in combination with safety belt around abdomen and/or chest.

Pull the two ends of the safety belt^(*) through the two openings on the side of the seat sling from the back and fasten them on the front. Tighten.



* Option: safety belt (#3473 1000)